

Getting Started

BATTERY INSTALLATION & REPLACEMENT (See Fig. 1)

To Open the Tornado Can Opener battery housing compartment:

1. Place the Tornado Can Opener in the palm of your hand with the on/off button facing up. Hold firmly.
2. Place the index finger of your free hand just above the on/off button. Grasp the left side (top section) with your thumb and the right side with your middle and ring fingers.
3. First pull the top in a backward motion; then lift in an upward motion as illustrated in figure 1.

Note-your Tornado Can Opener is two toned in color. The top section will release revealing the battery compartment (figure 1).

Install 4 AA alkaline or rechargeable batteries in the battery compartment according to the polarity (+/-) instructions. After batteries are installed, close the battery housing securely. Always replace all 4 batteries at once never mixing old and new batteries and/or different types of batteries.

PLEASE READ AND SAVE
USER MANUAL

User Manual

TORNADO
PATENT PENDING


TORNADO
CAN OPENER

For helpful videos on battery replacement and the proper operation of your Tornado Can Opener please visit our help website at:


www.helptornadocanopener.com

Or call 888-995-1070

Do not return your Tornado Can Opener to the point of purchase. Contact the website or number above for trouble shooting and/or return questions.



Parts



Care and Maintenance

1. If the TORNADO Can Opener slows during cutting, this may indicate a low battery level and the batteries should be replaced.
2. To clean, use a clean, damp cloth or sponge to wipe surface of can opener. Do not wash under running water or other liquids. Do not use solvents or abrasives to clean. Do not place in dishwasher.

Trouble Shooting

1. If the batteries are depleted and the Can Opener is still on the can, replace the batteries with a new set of batteries. (see Figure 1 for Battery Replacement)
2. The magnet on the bottom of the can opener will pick up can lid for easy removal. If the lid does not detach from the can, carefully lift the lid off the can by hand. Please note, the Tornado Can Opener makes a very fine cut so the separation of can and lid may not be immediately obvious.

NOTE: The Can Opener will not open rimless cans or cans with odd corners.

Limited 1 Year Warranty

Return unit with proof of purchase to:

Harvest Direct, LLC
Attn: Tornado Can Opener Return Dept
61 Accord Park Drive
Norwell, MA 02061 USA

REV0413